## Quick Reference Guide

# **FUSE** NETWORKS

### Mitel 5320/5320e IP Phone

**Quick Reference Guide** 



- Display
- Ring/Message Indicator
- Volume, Speaker, Mute Controls
- Fixed Function Keys
- Keypad
- Page Navigation Keys
- Personal Keys
- Speaker
- Handset



Speaker



Mute



Menu



Cancel





¬ Ison Transfer/Conference



Message

NOTE: For more information about other features on your 5320 IP Phone, refer to Fuse CloudVoIP Mitel Phone User Guide or contact your Fuse Account Manager.

#### Make a Call

- O Lift the handset OR.
- Press (1)
- 5 Dial the number OR
- Press a Speed Call key OR
- 4 Press 123 OR
- 5 Dial the prefix for external calls (e.g. 9) and the number.

#### Answer a Call

- Uift the handset OR
- Press (1), and begin speaking.

#### End a Call

- 4 Press X OR
- Replace the handset.

#### Place a Call on Hold

- Press \(\triangle \infty \). The line key flashes.
- Replace the handset if necessary.

#### Retrieve a Call from Hold

- (2) Lift the handset OR
- 3 Press (1).
- Press the flashing line key.

#### Retrieve a Message

- 4 Press It flashes when a message is
  - Follow the voice mail prompts to retrieve your message.

#### Transfer a Call

- 4 Press ASS
- Dial the number. Wait for an answer.
- (9) Hang up OR wait for the called party to answer, announce the transfer, and then hang up.

#### Conference a Call

- 4 Press A SOL
- 5 Dial the number of the next party. Wait for an
- 4 Press A SR.

#### Program a Speed Call

- 4 Press Menu OR
  - Press Settings.
  - Press Programmable Keys.
  - Press the key you wish to program.
  - Press Speed Call.
  - Press Edit Info and enter the label for the Speed Call.
  - Press Save.
  - Press Edit Number and enter the phone number for the Speed Call.
  - Press Save, and then press Save again.

  - Press Close and then press Close again.

#### Adjust Volume Levels

Adjust ringer volume while the phone is ringing. Adjust handset or speaker volume while using the handset or speaker.

- 3 Press repeatedly to raise the volume OR
  - repeatedly to lower the volume.
- 3 Press of to mute your microphone.