

Cordless Device Setup Guide

Cloud VoIP Cordless Device Setup Guide


PURPOSE

This document will guide you through the basic setup of the Mitel cordless accessory module, cordless handset and cordless headset. Mitel cordless accessory devices are supported with the use of the Mitel 5330, 5340 or 5360 IP Phone only. Should you have additional cordless device questions or require assistance beyond the scope of this document, please contact Fuse Networks Support at 1-888-676-3873.


Cordless Accessories Module Installation

The cordless accessories module allows for cordless handsets and headsets to be paired to your Mitel phone. The module is required if using any of these devices.


1. Remove the phone stand and disconnect **all** wires/cables from the phone
2. Remove the single Philips-head screw and detach the back plate.
3. With the back plate detached install the cordless accessory plug (3) included with your module.
4. Install the cordless accessory module in the back plate location, ensuring the connecting pins (4) are aligned.



5. Press the module into the back of the phone and seat it securely.
6. Using the screw (6) removed from the back plate, fasten the module to the phone.



[CAUTION: Attempting to remove the back plate on the telephone to install the Cordless Module before disconnecting the telephone's power supply may damage the telephone]




Cordless Device Setup Guide

Cordless Headset Installation

The cordless headset provides the capability to move around within an office or adjacent offices while using the Mitel phone. The cordless headset rests and recharges in a headset cradle that attaches to the rear-side of the phone

1. Remove the phone stand and disconnect all wires/cables from the phone
2. Remove the two Philips-head screws located to the left-rear side of the phone. *(These screws secure the chassis of the phone together)*
3. Install the cordless headset charging cradle on the left-rear side of the phone, securing in place with the longer screws (a) supplied with the cordless headset.
4. Connect the charging cradle cable (b) to the phone jack located on the cordless accessories module.




HEADSET CHARGING

- To charge the cordless headset, securely place it on the charging cradle. A green LED (Light Emitting Diode) will begin to flash on the charging cradle, indicating active charging.
- Once the green LED stops flashing and remains solidly lit, charging is complete.

Cordless Handset Installation

The cordless handset replaces a traditional corded handset and provides additional mobility while using the Mitel phone. The cordless handset rests and recharges in a handset cradle that attaches to the front of the phone.

1. Remove the phone stand and disconnect all wires/cables from the phone
2. Remove the blank cover (1) on the front of the phone at the bottom of the handset cradle by removing the single Phillips-head screw (3) inserted from the back of the phone.
3. Connect the charging cradle (2) connector to the connector inside the phone.
4. Insert the lip on the right side of the charging cradle into the slot on the phone and snap the cover into place.
5. Using the screw (3) you removed earlier, secure the charging cradle (2) from the back of the phone.



HANDSET CHARGING

- To charge the cordless handset, securely place it on the charging cradle. A green LED (Light Emitting Diode) will begin to flash on the handset, indicating active charging.
- Once the green LED stops flashing and remains solidly lit, charging is complete.

Cordless Device Setup Guide

FUSE NETWORKS

Pairing Your Cordless Device

Upon installation of the cordless device, it must be “paired” to the cordless accessories module for operation with your Mitel phone. Ensure your phone is powered on and working before pairing the cordless headset or handset.

Cordless Headset Pairing

1. Press and hold down the “pairing” button on the back of the cordless accessories module for up to 5 seconds.
2. The blue LED (Light Emitting Diode) on the cordless module will flash and your Mitel phone set will display the pairing screen.
3. Once the module LED is flashing press and hold down the cordless headset hook-switch (a) for up to 5 seconds.
4. The blue LED on the cordless headset will begin to flash.
5. After a few moments your Mitel phone will recognize the cordless headset and will prompt you with **“Would you Like to pair this device?”**
6. Select Yes to confirm device pairing.



Cordless Handset Pairing

1. Press and hold down the “pairing” button on the back of the cordless accessories module for up to 5 seconds.
2. The blue LED (Light Emitting Diode) on the cordless module will flash and your Mitel phone set will display the pairing screen.
3. Once the module LED is flashing press and hold down the cordless handset hook-switch (b) for up to 5 seconds.
4. The blue LED on the cordless handset will begin to flash.
5. After a few moments your Mitel phone will recognize the cordless handset and will prompt you with **“Would you Like to pair this device?”**
6. Select Yes to confirm device pairing.

